

MEGASAT
Brillantes Fernsehen

Bedienungsanleitung User Manual



Digitaler HD Satelliten Receiver Megasat HD570CI

Stand: Dezember 2011 V1.0

Inhalt


Sicherheitshinweise.....	3
Vorsichtsmaßnahmen.....	4
Zubehör.....	4
Vorderansicht.....	5
Rückansicht.....	5
Fernbedienung.....	6
Start.....	7-9
Batterie.....	7
Lebensdauer der Batterien.....	7
Reichweite der Fernbedienung.....	7
Vorbereitung.....	8
Anschluss an den TV.....	8
Schnellinstallation.....	9
Hauptmenü.....	9
Programmbearbeitung.....	10
Installation.....	11
System Einstellung.....	12
Werkzeug.....	13
Spiele.....	14
Technische Daten.....	15
Fehlerbehebung.....	16

Sicherheitshinweise

Sehr geehrter Kunde,

vielen Dank für den Kauf dieses DVB Satelliten-Receiver. Bitte lesen Sie diese Anleitung sorgfältig durch, bevor Sie Ihr Produkt benutzen und achten Sie genau auf die Vorsichtsmaßnahmen, die unten aufgeführt sind.

- Dieses Produkt kann nur an einer Stromversorgung mit ~ 230V, 50Hz betrieben werden.
- Um Brände oder Stromschläge zu vermeiden, sollten Sie dieses Gerät nicht der Feuchtigkeit aussetzen.
- Um die Gefahr von Feuer, Stromschlag oder einer Störung zu verringern, verwenden Sie nur das empfohlene Zubehör.
- Der Netzstecker als Trennvorrichtung muss frei zugänglich bleiben.
- Halten Sie mind. 5cm Abstand um das Gerät herum frei für eine ausreichende Belüftung.
- Die Belüftung sollte nicht durch Zeitungen, Tischtüchern, Vorhängen oder sonstigen Gegenständen abgedeckt werden.
- Keine offenen Flammen wie beispielsweise angezündete Kerzen auf das Gerät stellen.
- Batterien dürfen nicht übermäßiger Wärme wie Sonnenschein, Feuer oder dergleichen ausgesetzt werden.
- Korrekte Entsorgung dieses Produkts.



Diese Markierung zeigt an, dass dieses Produkt nicht mit dem Hausmüll in der gesamten EU beseitigt werden darf. Um mögliche Schäden für die Umwelt oder die menschliche Gesundheit nicht durch unkontrollierte Entsorgung zu fördern, Recycling Sie es um die nachhaltige Wiederverwertung von Ressourcen zu fördern. Für die Rückgabe Ihres Altgerätes nutzen Sie bitte das Rückgabe- und Sammelsystem oder kontaktieren Sie den Händler, bei dem das Produkt gekauft wurde. Sie können dieses Produkt für die Umwelt recyceln.

Dieses Produkt wurde hergestellt, und entspricht den internationalen Sicherheitsstandards. Bitte lesen Sie die folgenden Sicherheitshinweise vor Gebrauch.

ÜBERLASTUNG

Überlasten Sie nicht die Wandsteckdose, das Verlängerungskabel oder Adapter, da dies zu Brand oder Stromschlag führen.

REINIGUNG

Trennen Sie das Gerät aus der Steckdose vor der Reinigung. Verwenden Sie keine Aerosol-Produkte, um ein Produkt zu reinigen. Staub der äußeren Oberfläche mit einem Tuch reinigen, das leicht mit Wasser (keine Lösungsmittel) befeuchtet ist.

Anschließen an Antenne

Trennen Sie das Gerät vom Netz bevor Sie sie an die Antenne anschließen. Andernfalls kann es zu Schäden am Produkt und Antenne kommen.

Anschluss am TV

Ziehen Sie das Netzkabel bevor sie den Receiver am TV anschließen. Andernfalls kann es zu Schäden am Produkt und Antenne kommen.

ERDUNG

Das Antennenkabel muss an dem Antennensystem geerdet sein und muss den lokalen Elektro-Sicherheitsstandards entsprechen.

LAGE

Der Receiver ist nur für den Innenbereich konzipiert. Installieren Sie nicht das Produkt, wo es hellem Licht oder direkter Sonneneinstrahlung ausgesetzt wird.

Vorsichtsmaßnahmen

Folgen Sie den Anweisungen bevor Sie das Gerät benutzen.


- Schutz des Netzkabels
- Bitte Beschwerde der folgenden Bestimmungen zu Fehlfunktionen, Feuer und elektrischen Schlägen oder anderen Schäden an menschlichen Körpers zu vermeiden.
- Vergewissern Sie sich zu verbinden und trennen Sie das Netzkabel mit der Steckdose.
- Schließen Sie keine oder ziehen Sie das Netzkabel mit nassen Händen.
- Trennen Sie die Netzkabel von Heizgeräten entfernt wie möglich.
- Legen Sie keine schweren Gegenstände auf das Netzkabel.
- Verwenden Sie keine Reparatur oder rekonstruieren das Netzkabel ohne Genehmigung.
- Reinigen Sie den Stecker regelmäßig.
- Cut off und trennen Sie das Netzkabel sofort, wenn das Produkt heruntergefallen ist oder beschädigt wurde.
- Cut off und trennen Sie das Netzkabel sofort, wenn Sie das Produkt ist das Rauchen, Brennen oder verrauscht zu finden.
- Location
- Installieren Sie das Produkt in folgenden Orten,
- Wo kann Sonnenlicht aussetzen oder Wärme Ressourcen wie Wärme registrieren und Herd zu lenken.
- Umgebungstemperatur über 35 ° C Umgebungstemperatur oder Luftfeuchtigkeit über 90%.
- staubigen Ort.
- Wo kann es durch das Magnetfeld oder statische Elektrizität zu beeinflussen.
- Wo kann es zu Stößen, Vibrationen oder Fallenlassen Thema.
- Nichtgebrauch
- Schalten Sie das Produkt in den Standby-Status oder das Gerät auszuschalten, wenn das Produkt nicht verwendet werden. Ziehen Sie den Netzstecker aus der Steckdose, wenn das Produkt automatisch in den Leerlauf für eine lange Zeit.
- Stecken Sie keine Finger oder andere Gegenstände in das Produkt
- Es kann zu Schäden am Produkt oder gar verletzt menschlichen Körpers durch das Berühren der inneren Teile des Produkts aufgrund der hohen Spannung.
- Öffnen Sie nicht das Produkt.
- Legen Sie keine Gegenstände auf das Produkt.
- Halten Sie Wasser und magnetischen Dinge weg
- Kontakt mit der Flüssigkeit kann zu schweren Schäden führen, halten Sie bitte das Produkt von ihm weg.
- Das Produkt fern von magnetischen Dinge, wie zum Beispiel Lautsprecher etc.
- Position
- Stellen Sie das Gerät auf einer horizontalen Fläche. Stapeln Sie nicht schwere Sachen drauf.
- Stellen Sie das Produkt unter die Lupe oder anderen Geräten, die Wärme abstrahlen.
- Signal-Interferenz
- Unter der Voraussetzung des TV-Signal zu empfangen Situation kann TV Set bekommen Signalstörungen, wenn Sie ein Fernsehprogramm mit dem DVB-T auf. Dies ist nicht bedeutet, dass das Produkt oder die TV Set Fehlfunktion. Bitte schalten Sie das DVB-T, während Sie das TV.

Zubehör

Packen Sie den Inhalt des Kartons aus und vergewissern sich, ob Folgendes im Lieferumfang enthalten ist:


Receiver	1
Fernbedienung	1
Bedienungsanleitung	1
Batterien (AAA)	2

Vorderansicht




1. Power/Standby Schalter
2. Programm „runter“ Schalter
3. Programm „rauf“ Schalter
4. IR Empfänger
5. USB LED (Das LED leuchtet grün im USB Betrieb.)
6. Power/Standby LED (Das LED leuchtet grün im Betrieb und rot im Standby.)
7. Display
8. CI-Module Slot (Hinter der Klappe)

Rückansicht



1. VCR SCART-Buchse
2. HDMI Buchse
3. USB Anschluss
4. TV SCART-Buchse
5. ZF IN
6. ZF OUT
7. Audio-Ausgang – Links
8. Audio-Ausgang – Recht
9. Digital-Ausgang Koaxial
10. Video-Ausgang
11. AC IN

Fernbedienung		Name	Beschreibung
 <p>The diagram shows a MEGASAT HD570CI remote control. It features a standard numeric keypad (0-9), a directional pad with an OK button, and various function buttons including POWER, MODE, F2, F1, TV/R, MUTE, and navigation keys. Red lines connect numbered callouts (1-40) to specific buttons or features on the remote.</p>	1	Power	Schaltet um zwischen Betrieb und Standby
	2	F2 Taste	
	3	Mode	Wechselt zwischen den HDMI Auflösungen
	4	Nummernblock	Um Programme anzuwählen oder zur Programmierung
	5	Menü	Menüeinstellungen
	6	Exit	Verlässt das aktuelle Menü
	7	Navigation	Tasten zur Navigation
	8	Lautstärke erhöhen	Erhöht die Lautstärke
	9	Lautstärke senken	Verringert die Lautstärke
	10	Teletext	Aufrufen der Teletext Anzeige
	11	Untertitel	Aktiviert den Untertitel (wenn vorhanden – sendungsabhängig)
	12	USB	Wechselt in den USB Betrieb
	13	FIND	Suchfunktion für z.B. Programmsuche
	14	LIST	Öffnet die Abspielliste
	15	Audio	Wechselt zu den Audioeinstellungen
	16	Zurück	Lied/Track/Kapitel zurück
	17	Vorwärts	Lied/Track/Kapitel vorwärts
	18	Zeitlupe	Zeitlupe bei Filmwiedergabe.
	19	Start / Pause	Start / Pause
	20	Stopp	Stopp
	21	Aufnahme	KEINE FUNKTION
	22	Rückwärts spulen	Schnelles Rückwärts spulen
	23	Vorwärts spulen	Schnelles Vorwärts spulen
	24	Zoom	Zoomfunktion
	25	RECALL	Zurück zum letzten Programm
	26	Sleep Taste	Automatische Abschaltung
	27	Seite runter	Blockweise nach unten
	28	Mosaik	Mosaikfunktion für mehrere Sender auf einem Bildschirm
	29	Seite hoch	Blockweise nach oben
	30	Programm runter	Schaltet ein Programm runter
	31	Programm rauf	Schaltet ein Programm aufwärts
	32	OK	Aktiviert die Programmübersicht/ Bestätigt die aktuelle Auswahl
	33	INFO	Kanal Information
	34	SAT	Satellitenauswahl
	35	EPG	Elektronischer Programmführer
	36	FAV	Wechselt zu den Favoritenlisten
	37	Timer	Timer (für automatische Einschaltung)
	38	F1 Taste	Optionstaste
	39	MUTE	Stummschaltung
	40	TV/R	Umschaltung TV und Radio


Start

Batterie

Setzen Sie die Batterien ein und achten Sie darauf (wie auf der Abbildung), dass der + und – Pol richtig eingelegt ist.

Lebensdauer der Batterien

- In der Regel halten Batterien ca. 1 Jahr. Je nach dem wie oft Sie die Fernbedienung benutzen.
- Ersetzen Sie die Batterien wenn die Fernbedienung nicht mehr funktioniert.
- Verwenden Sie 2x AAA Batterien.



Hinweise

Wischen Sie den Elektrolyten von der Fernbedienung Fach und durch neue Batterien ersetzt. Falls Elektrolyt passiert mit Ihrer Haut berühren, waschen Sie sie gründlich mit klarem Wasser abspülen.


- Verwenden Sie keine aufladbaren Batterien (Ni-Cd) Batterien.
- Versuchen Sie die Batterien nicht aufzuladen, kurzzuschließen, zu zerlegen, zu erhitzen oder ins Feuer zu werfen.
- Nicht fallen lassen, ansonsten kann ein Teil der Fernbedienung beschädigt werden und es kann zu Fehlfunktionen führen.
- Verwenden Sie nicht alte und neue Batterien zusammen.
- Bitte entfernen Sie die Batterien, wenn die Fernbedienung über einen längeren Zeitraum nicht verwendet wird, andernfalls kann es zum Auslaufen von Elektrolyt kommen und zu Fehlfunktionen führen.
- Falls Elektrolyt ausgelaufen ist, entfernen Sie es vom Batteriefach und setzen neue Batterien ein. Wenn Elektrolyt mit Ihrer Haut in Verbindung kommt, reinigen Sie gründlich Ihre Haut mit klarem Wasser.

Reichweite der Fernbedienung

- Richten Sie die Fernbedienung auf den IR-Empfänger. Die Fernbedienung ist in einem Abstand von ca. 5 Metern effektiv und in einem Winkel von etwa 60 Grad, wie in Abbildung B gezeigt
- Die effektive Reichweite kann mit der Helligkeit im Raum leicht variieren.

Hinweise

- Die Fernbedienung wird nicht funktionieren, wenn Hindernisse zwischen der Fernbedienung und dem Sensor sind.
- Die Fernbedienung kann nicht mit anderen Geräten verwendet werden.




Vorbereitung

- Alle Geräte müssen entsprechend dieser Bedienungsanleitung angeschlossen werden.
- Schalten Sie dieses Produkt und andere Geräte vor dem Anschließen aus.
- Lesen Sie die Bedienungsanleitung sorgfältig durch, bevor Sie andere Geräte anschließen.
- Schließen Sie das Audio-und Video-Kabel richtig an.
- Wenn Sie dieses Produkt mit dem Fernseher betreiben, wird nur eine Art von Video-Ausgangs-Format akzeptiert. Bitte wählen Sie einen entsprechenden Video-Modus für das Produkt, sonst wird das Bild verzerrt dargestellt.


Anschluss an dem TV mit einer Scart-Verbindung

1. Antenne (nicht im Lieferumfang enthalten)
2. TV (nicht im Lieferumfang enthalten)
3. SCART-Kabel für den Anschluss von Fernseher und DVB-S-Empfänger (nicht im Lieferumfang enthalten)
4. AC IN



Anschluss an dem TV mit einer Scart-Verbindung

1. Antenne (nicht im Lieferumfang enthalten)
2. TV (nicht im Lieferumfang enthalten)
3. HDMI Kabel (nicht im Lieferumfang enthalten)
4. AC IN



Schnellinstallation

1. Schließen Sie dieses und andere Geräte richtig an. Schließen Sie das Netzkabel an und drücken Sie die [STANDBY]-Taste (keine Notwendigkeit für die erste Verbindung).
2. Schließen Sie das Netzkabel an und drücken Sie [STANDBY]-Taste um zu starten.
3. Drücken Sie [MENU]-Taste, um in das Setup zu gelangen. Drücken Sie [▲ / ▼]-Taste, wählen Sie "Extras" und laden Sie die Werkseinstellungen. Werkseitig ist das Passwort "0000".
4. Wählen Sie "Installation" mit der Taste [CH-/CH +] und drücken Sie [VOL ▶]-Taste, um das Setup. Passwort: 0000.
 - Wählen Sie "Satelliten List", um den Satelliten zu auszuwählen. Drücken Sie [EXIT]-Taste.
 - Wählen Sie "Antennen Setup" und drücken Sie [VOL ▶], um in das Setup zu gelangen. Wählen Sie "LNB Freq" auf High Frequenz und andere Parameter-Setup. Drücken Sie [EXIT]-Taste.
 - Wählen Sie "Single / Multi Satelliten" und drücken Sie [VOL ▶], um in das Setup zu gelangen. Nach dem Setup, drücken Sie [VOL ▶], um die automatische Suche zu starten.

Hauptmenü

Drücken Sie MENU um in das Hauptmenü zu gelangen, die 6 Untermenüs sind:

- **Programme bearbeiten**
- **Installation**
- **Systemeinstellungen**
- **Werkzeuge**
- **Spiel**

Drücken Sie [CH ▲ / ▼] Taste, um Menüpunkte auszuwählen, drücken Sie die Taste OK, um in das Untermenü zu gelangen. Drücken Sie [EXIT]-Taste, um zum vorherigen Menü zurückzukehren.

Hinweis:

1. Die vier Navigationstasten (▲ / ▼ / ◀ / ▶), haben die gleiche Funktion wie die OK und die EXIT-Taste in den Menüs.
2. Einige Tasten haben unterschiedliche Funktionen in verschiedenen Menüs. Bitte informieren Sie sich nach den Informationen auf dem Bildschirm.
3. Programmierbare Tasten (Farbtasten) hängen von dem jeweiligen Menü ab in dem Sie sich gerade befinden. Bitte informieren Sie sich nach den Informationen auf dem Bildschirm.

Programme bearbeiten

Wählen Sie Kanäle im Hauptmenü und drücken Sie [OK]-Taste, um in das Untermenü zu gelangen. Es gibt 4 Optionen zur Auswahl:

- TV Programmliste
- Radio Programmliste
- Alle löschen
- Programmliste als Standard speichern

TV Programmliste

Bewegen Sie den Cursor auf "TV Programmliste" und drücken Sie [OK]-Taste.

Verwenden Sie Taste [CH ▲ / ▼] und drücken Sie die [OK]-Taste zur Bestätigung.

Verwenden Sie die programmierbaren Tasten (Farbtasten) zur Einrichtung.

Fav-Taste ist aktiviert, wenn die Favoriten Kanäle eingestellt wurden. Passwort ist: 0000.

FAV: Drücken Sie [FAV], um die "FAV"-Symbol anzuheben. Verwenden Sie [CH ▲ / ▼] Taste, um den Kanal auszuwählen und drücken Sie [OK]-Taste, um den gewählten Kanal in 8 verschiedene Favoritenlisten Gruppen auszuwählen. Drücken Sie [OK] zweimal, um das Setup abzubrechen. Drücken Sie [EXIT]-Taste um zu beenden.

Sperren: Drücken Sie [ROT], um das "Sperren"-Symbol anzuheben. Verwenden Sie [CH ▲ / ▼] Taste, um den Kanal auszuwählen und drücken Sie [OK]-Taste zum Sperren, drücken Sie [OK]-Taste erneut um das Sperren aufzuheben. Drücken Sie [EXIT]-Taste, um das aktuelle Menü zu verlassen und zu speichern.

Überspringen: Drücken Sie [Green], um die "Skip"-Symbol anzuheben. Verwenden Sie [CH ▲ / ▼] Taste, um den Kanal auszuwählen der das gewählte TV-Programm überspringen soll.

Move: Drücken Sie [GELB], um "Move"-Symbol anzuheben. Verwenden Sie [CH ▲ / ▼] Taste, um den Kanal auszuwählen und drücken Sie [OK]-Taste, um die Auswahl zu bestätigen. Verwenden Sie [CH ▲ / ▼]-Taste um zu bewegen und die [OK]-Taste, um Bewegung zu bestätigen. Drücken Sie [EXIT] um zu beenden.

Edit: Drücken Sie [BLAU]-Taste, um in den "edit"-Modus zu gelangen. Im "Edit"-Modus, drücken Sie die [ROT]-Taste, um Kanäle nach Name (AZ) / Name (ZA) / Frei / Sperr Art; drücken Sie [GRÜN]-Taste zum Bearbeiten (umbenennen) des gewählten Kanals. Drücken Sie die [ROT]-Taste zu alpha zwischen aktiviert und kleine Verschiebung, Drücken Sie [GRÜN]-Taste um die Eingabe zu löschen, drücken Sie [GELB]-Taste zur Bestätigung drücken Sie [BLAU]-Taste um abzubrechen.

Radio Programmliste

Alle gefundenen Radiosender werden hier aufgelistet.

Siehe den Betrieb von TV Programmliste (Punkt 1.1) für detaillierte Vorgänge.

Alle löschen

Löschen Sie alle TV-und Radioprogramme nach den Infos auf dem Bildschirm.

Programmliste als Standard speichern

Bitte halten Sie sich an den Infos auf dem Bildschirm.

Installation

Wählen Sie die Installation im Hauptmenü und drücken Sie [OK]-Taste, um in das Untermenü zu gelangen. Es gibt 9 Untermenüpunkte:

- Antennenanschluss
- Satellitenliste
- Antenneneinstellung
- Einzel-Satelliten Suche
- Multi-Satelliten Suche
- TP-Liste

Antennenanschluss

- Feste Antenne
- Motorgesteuerte Antenne

Satellitenliste

Bewegen Sie den Cursor auf "Satellitenliste" und drücken Sie [OK]-Taste, um in das Untermenü zu gelangen. Verwenden Sie [CH ▲ / ▼], um den Satelliten auszuwählen.

Edit: Drücken Sie die [ROT]-Taste, um die Satelliten zu bearbeiten. Bitte folgen Sie den Infos auf dem Bildschirm. Verwenden Sie [ROT]-Taste, Alpha zwischen aktiviert und kleine Verschiebung. Verwenden Sie die [GRÜN]-Taste um die Eingabe zu löschen. Verwenden Sie die [GELB]-Taste, um den Editor zu bestätigen. Drücken Sie die [BLAU]-Taste, um den Editor abzubrechen

Hinzufügen: Drücken Sie die [GRÜN]-Taste um einen Satelliten hinzuzufügen. Bitte arbeiten nach dem Kapitel "Edit".

Löschen: Verwenden Sie die [CH ▲ / ▼], um den Satelliten auszuwählen und die [OK]-Taste, um die Auswahl zu bestätigen. Drücken Sie die [BLAU]-Taste, um den ausgewählten Satelliten zu löschen. Drücken Sie [EXIT]-Taste um zu beenden.

Antenneneinstellung

Bewegen Sie den Cursor auf "Antennensetup" und drücken Sie [OK]-Taste, um in das Untermenü zu gelangen. Verwenden Sie [CH ▲ / ▼], um auszuwählen, und die [VOL ◀ / ▶] Tasten, um die Parameter zu ändern. Signalstärke und Signalqualität wird am unteren Rand des Fensters angezeigt werden.

- Satellit: Wählen Sie einen Satelliten.
- LNB Freq: Drücken Sie [OK] Taste, um eine richtige LNB-Frequenz zu wählen.
- Transponder: Drücken Sie [OK]-Taste, um einen Transponder auszuwählen.
- DiSEqC1.0: Drücken Sie [OK]-Taste, um einen DiSEqC Port zu wählen.
- 22K: Verwenden Sie [VOL ◀ / ▶] Tasten um zu aktivieren oder deaktivieren.
- Polarität: Verwenden Sie [VOL ◀ / ▶] Tasten, um eine Polarität Spannung zu wählen:

Auto, H (horizontal) und V (vertikal).

Einzel-Satelliten-Suche

- Satellit: Drücken Sie [OK]-Taste, um einen Satelliten zu wählen.
- Nur FTA: Ja (Suche in freien Kanälen) / Nein (Suche kostenlose und kostenpflichtige Kanäle)
- Programmsuche: TV / Radio / TV + Radio
- Netzwerk Suche: JA/NEIN (wird aktiviert, wenn "Scan Mode" im "Preset Scan"-Modus)
- Scan-Modus: Auto Scan / Preset Scan
- Suche: Suche starten.

Multi-Satelliten-Suche

- Satellit: Drücken Sie [OK]-Taste, um einen Satelliten zu wählen.
- Nur FTA: Ja (Suche in freien Kanälen) / Nein (Suche kostenlose und kostenpflichtige Kanäle)
- Programmsuche: TV / Radio / TV + Radio
- Netzwerk Suche: JA/NEIN (wird aktiviert, wenn "Scan Mode" im "Preset Scan"-Modus ist)
- Scan-Modus: Auto Scan / Preset Scan
- Suche: Suche starten.

TP Liste

Bewegen Sie den Cursor auf "TP-Liste" und drücken Sie die [OK]-Taste, um in das Untermenü zu gelangen. Drücken Sie die [EXIT]-Taste um zu beenden. Siehe "Satellitenliste" für Detail-Vorgänge von Bearbeiten / Hinzufügen / Löschen / Suchen.

System Einstellungen

Wählen Sie Setup im Hauptmenü und drücken Sie die [OK]-Taste, um in das Untermenü zu gelangen. Es gibt 11 Untermenüpunkte:

- Sprache
- TV System
- Bildschirm-Einstellung
- Lokalzeit-Einstellung
- Timer-Einstellung
- Kindersicherung
- OSD Einstellung
- Favorit
- Audio Anpassung
- Erweiterte Einstellungen

Sprache

Englisch, Französisch, English und etc.

Erste Audio Sprache: Englisch, Französisch, English und etc.

Zweite Audio Sprache: Englisch, Französisch, English und etc.

Untertitel Sprache: Englisch, Französisch, English und etc.

Teletext Sprache: Englisch, Französisch, English, English, Französisch, English und etc.

TV-System

Video-Auflösung

Aspect Ratio: Auto / 4:3 LB (Letter Box) / 4:3 PS (Pan Scan) / 16:9

Video Out: RGB / HDMI

Bildschirm-Einstellung

Helligkeit: 0-100 / Kontrast: 0-100 / Sättigung: 0-100

Lokalzeit-Eeinstellung

GMT Usage / GMT Offset / Summer Time / Datum / Zeit

Timer-Einstellung

Timer-Modus: einmal / täglich / wöchentlich / monatlich / aus

Timer Service / Startkanal / Start Datum / On Time / Dauer

Kindersicherung

Standard-Kennwort: 0000

Menu Lock: Ein / Aus. Wenn Sie EIN wählen wird ein Passwort benötigt beim Suchlauf.

Channel Lock: Ein / Aus. Das Passwort wird benötigt, um gesperrte Programme zu sehen.

Neues Passwort: Neues Passwort mit den Zifferntasten wählen

Password bestätigen: Geben Sie das neue Kennwort mit den Zifferntasten ein.

OSD Einstellung

Anzeige der Untertitel

OSD Timeout: 1-10 Sekunden; OSD Transparenz: off/10% / 20% / 30% / 40%

Favoriten

Es gibt 10 Favoritengruppen. Drücken Sie die OK-Taste, um die Gruppe umzubenennen.

GELB: Wechselt zwischen Groß- und Kleinbuchstaben

ROT: Eingabe abbrechen

BLAU: Eingabe bestätigen

Audio Anpassung

AD Service: OFF / ON

Audio verwenden als Standard: OFF / ON

Audio Lautstärke-Anpassung: 0/1/2/3/-3/-2/-1

Erweiterte Einstellung

LNB Power: OFF / ON; Kanäle: Frei / Verschlüsselt / Alle; Ber: Off / On

Werkzeuge

Wählen Sie Extras und drücken Sie die [OK]-Taste, um in das Untermenü zu gelangen.

Es gibt 9 Untermenüs:

- Informationen
- Werkseinstellung
- Common Interface
- Upgrade über USB
- Speichern auf USB
- Media Player
- USB-Gerätes sicher entfernen

Information

Sie sehen die System-Informationen zu diesem Gerät

Werkseinstellung

Das Standard-Passwort lautet "0000"

Common Interface

Slot1

1) Informationen zu der CI-Karte.

2) Bitte stecken Sie eine gültige Karte ein. Wenn Sie Schwierigkeiten bei der Steckkarte haben, bitte nehmen Sie sie heraus und überprüfen Sie ob die Karte richtig eingelegt ist. Achten Sie darauf, dass die Karte auch aktuell und nicht abgelaufen ist.

3) PCMCIA-Karte ist mit einer Dicke von nicht mehr als -5.00mm vorgesehen.

Upgrade über USB

Stecken Sie ein Flash-Laufwerk (USB Stick) ein und laden alle Datei mit "*.abs" auf den Stick.

Im Menü "Extras" wählen Sie "Upgrade über USB" und drücken auf OK, um das Upgrade zu starten. Wählen Sie "ALL CODE", wird die Upgrade-Datei automatisch gefunden. Wählen Sie "Start", um die Upgrade-Datei zu laden und zu starten.

Hinweis:

1. Trennen Sie nicht die Stromzufuhr während des Upgradevorganges.
2. Werkseinstellung muss nach dem Upgrade durchgeführt werden.

Speichern auf USB

Stecken Sie ein Flash-Laufwerk (USB Stick) ein und gehen Sie zu "Speichern auf USB".

- Speicher Methode: Alle Code / Radio Hintergrund / Default db
- Datei speichern
- Start

Media Player (USB)

Das Gerät stellt automatisch die Verbindung zum USB-Laufwerk her, wenn es eingesteckt ist. Durchsuche USB-Gerät nach Dateien aus dem "Media Player"-Untermenü, dass sich im Menü "Extras" befindet.

Hinweis:

1. MP3/JPEG/BMP Formate werden unterstützt.
2. Media player Untermenü kann nicht ohne den Anschluss von USB-Gerät geöffnet werden.
3. Drücken Sie "EXIT"-Taste um zu beenden.

USB-Gerät sicher entfernen

Bewegen Sie den Cursor auf " USB-Gerät sicher entfernen" und drücken Sie die [OK]-Taste, warten Sie einige Sekunden und entfernen Sie das USB-Gerät.

Mailbox

Bewegen Sie den Cursor auf "Mailbox" und drücken Sie die [OK] Taste, um die E-Mails von Unternehmen als Betreiber zu suchen.

Spiele

Wählen Sie "Spiele" im "Werkzeuge"-Menü und drücken Sie die OK-Taste, um in das Untermenü zu gelangen. Es gibt 2 Untermenüs:

- Othello
- Sudoku

Technische Details

Items	Features
Eingangsfrequenz	950~2150 MHz (C/KuCompatible)
Eingangssignal	- 65 ~ - 30dBm
RF Input Anschluss	IEC169 - 2, weiblich
Eingangs Widerstand	75Ω
Demodulation	QPSK , Compatible SCPC & MCPC
Symbolrate	2~45 Mbit/s
Code Rate	1/2, 2/3, 3/4, 5/6, 7/8
Video Decotierung	ISO/IEC13818-2 MPEG2 (MP@ML)
Video Auflösung	720×576 (PAL); 720×480 (NTSC)
Video Eingangsrate	15 Mbit/s Max
Teletext	DVB-TXTETSI/EN300472
Audio Decotierung	ISO/IEC13818 - 3
Audio Signale	Stereo, Monophony (L, R), SPDIF
Audio Sample Rate	32 , 44.1, 48KHz
USB Port	USB2.0
Format	MP3/JPEG/BMP
System	FAT32, NTFS
Stromversorgung	~ 176-264V , 50Hz
Strom	~230V, 50Hz
Standby Verbrauch	≤ 0,5W
Verbrauch im Betrieb	~ 8Watt – max. 12 Watt
Temperaturbereich	0~40°
Max. Luftfeuchtigkeit	<90%
Gewicht	< 1.5 Kg
Abmessungen	266(B)×188(T)×42(H)mm

Hinweis:

Gewicht und Abmessungen sind nicht die absolut exakten Werte.
Technische Details können jederzeit geändert werden (nach Hersteller) ohne vorherige Ankündigung.

1 Konformitätserklärung

Hiermit wird die Übereinstimmung mit folgenden Richtlinien/Normen bestätigt:

- Richtlinie zur elektromagnetischen Verträglichkeit 2004/108/EG
 - EN 55013: 2001 + A1: 2003 + A2: 2006
 - EN 55020: 2007
 - EN 61000-3-2:2006 + A1:2009 + A2:2009
 - EN 61000-3-3:2008
- Niederspannungsrichtlinie 2006/95/EG
 - EN 60065: 2002 + A1: 2006 + A11: 2008

Fehlerbehebung

Fehler	Mögliche Ursachen	Lösungsvorschläge
Kein Strom	Das Netzkabel ist nicht richtig angeschlossen	Vergewissern Sie sich, dass das Kabel richtig angeschlossen ist. Schalten Sie das Gerät 5-10 min. aus und versuchen Sie es erneut.
Es kann keine Suche durchgeführt werden	Die Antenne ist nicht richtig ausgerichtet	Richten Sie die Antenne richtig aus
	Falscher Parameter wurde eingegeben	Eingangs Frequenz, Bandbreite-Parameter korrekt einstellen
Kein Bild	Ausgangskabel wurde falsch angeschlossen	Schließen Sie das Kabel richtig an.
	Videoausgang stimmt nicht mit dem TV Gerät überein	Setzen Sie das Gerät in die Werkseinstellung zurück
Keine Farbe	Videoausgang stimmt nicht mit dem TV Gerät überein	Farbeeinstellungen zurücksetzen
Bildstörungen beim Programmwechsel	normal	
Die Fernbedienung hat keine Funktion	Batterien sind nicht richtig eingelegt	Legen Sie die Batterien richtig ein
	Batterien sind leer	Ersetzen Sie die Batterien
	Die Reichweite ist erschöpft	Bedienen Sie die Fernbedienung nur in Reichweite des Empfängers
	Der Sensor wird durch zu helles Licht gestört	Überprüfen Sie die Lichtverhältnisse
Audio und Untertitel haben nicht die gewählte Sprache	Sie haben die richtige Sprache nicht ausgewählt	Drücken Sie die Audio Taste um die richtige Sprache einzustellen
Kein Ton	Das Gerät ist im Stumm-Modus	Schalten Sie den Stumm-Modus aus
	Lautstärke ist zu leise eingestellt	Erhöhen Sie die Lautstärke
	Kabel ist nicht richtig angeschlossen	Schließen Sie das Kabel richtig an.
Verzerrung des Bildes, Programm kann nicht normal empfangen werden.	Zu viel Signal von der Antenne	Richten Sie die Antenne richtig aus
USB Laufwerk kann nicht gelesen werden	Der USB Stick ist nicht richtig verbunden	Schließen Sie das Kabel der Festplatte richtig an oder überprüfen Sie den Anschluss des USB Sticks
	Der USB Stick (oder Festplatte) braucht zu viel Strom	Schließen Sie eine externe Stromquelle an (bei Festplatte)
	Der USB Stick geht in den Selbstschutz das ein Kurzschluss vorliegt	Beheben Sie den Kurzschluss und schließen Sie das Gerät neu an

MEGASAT b2c-electronic GmbH, Industriestraße 4a, 97618 Niederlauer

Web: www.megasat.tv Mail: info@megasat.tv

MEGASAT
Brillantes Fernsehen

User Manual



Digital HD Satellite Receiver

Megasat HD570CI

Contents

Safety Instructions	3
Precautions	4
Features	4
Accessories	5
Front Panel	5
Rear Panel	5
About Remote Control	6
Start	7-9
Battery Installation	7
Service Life of Batteries	7
Operation Range of Remote Control	7
Basic connections	8
Preparation	8
Connecting TV-Set	8
Fast Installation	9
Advanced Operation	9-13
Main Menu	9
Edit Channel	9-10
Installation	10-11
System Setup	11-12
Tools	12-13
Game	13
Appendix	14-16
Maintenance	14
Terminology	14
Specifications	15
Troubleshooting	16

1.1.1 Accessories

After purchasing receiver, unpack it and check to make sure that all of the following items are included in the packaging.


Receiver	one piece
Remote control	one piece
User Manual	one piece
Batteries (AAA)	two pieces

Safety Instructions

Dear customer,

Thank you for purchasing this DVB Satellite Receiver. Please read this manual carefully before operating your product and pay close attention to the precautions which are mentioned below.

- ◆ This product only can be operated where the mains supply is ~230V, 50Hz.
- ◆ To avoid fire and electric shock, do not expose this equipment to rain or moisture.
- ◆ The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquid, such as vases, shall be placed on the apparatus.
- ◆ To reduce the chance of fire, electric shock, or annoying interference, use only the recommended accessories.
- ◆ The mains plug is used as the disconnect device, the disconnect device shall remain readily operable.
- ◆ Keep not less than 5cm distances around the apparatus for sufficient ventilation.
- ◆ Keep the ventilation should not be impended by covering the openings with items such as newspapers, table-cloths, curtains, etc.
- ◆ No naked flame sources, such as lighted candles, should be placed on the apparatus.
- ◆ Batteries shall not be exposed to excessive heat such as sunshine, fire or the like.
- ◆ The label was silk-printed on the exterior of the bottom of the apparatus.
- ◆ Correct Disposal of this product.
- ◆ To reduce the chance of fire, electric shock, do not open the cover when it works.



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

This product has been manufactured to conform to the International Safety Standards. Please peruse the following safety precautions before use.

OVERLOADING

Do not overload a wall outlet, extension cord or adapter as this may result in fire or electric shock.

CLEANING

Disconnect the product from the wall outlet before cleaning. Do not use any aerosol products to clean the product. Dust the outer surface with a cloth lightly dampened with water (no solvents).

CONNECTING TO ANTENNA

Disconnect the product from mains before connecting or disconnecting to antenna. Otherwise, it may damage the product and antenna.

CONNECTING TO TV SET

Unplug the power cord when connecting or disconnecting to TV Set. Otherwise, it may damage the product and antenna

EARTHING

The antenna cable must be earthed to the antenna system and the Earthing System must comply with the local Electric Safety Standards.

LOCATION

The DVB-S is designed for indoor use only. Do not install the product where it may expose to bright light or direct sunlight.

1.1.2 Precautions

Peruse the following precautions before using.

◆ Power Cord Protection

Please complaint the following regulations to avoid malfunction, fire and electric shock or other damage to human body.

◆ Make sure to connect and disconnect the power cord with holding the plug.

◆ Do not connect or disconnect the AC power with wet hands.

◆ Separate the AC power cord from heating appliances as distance as possible.

◆ Do not stack any heavy objects on the AC power cord .

◆ Do not repair or reconstruct the AC power cord without authorization.

◆ Clean the plug regularly.

◆ Cut off the power and disconnect the AC cord immediately if the product has been dropped or damaged.

◆ Cut off the power and disconnect the AC cord immediately if you find the product is smoking, burning or noisy.

Location

Do not install the product in following locations,

◆ Where it may expose to direct sunlight or heat resources such as heat register and stove.

◆ Ambient temperature over 35°C or ambient atmospheric moisture over 90%.

◆ Dusty place.

◆ Where it may influence by magnetic field or static electricity.

◆ Where it may subject to physical shock, vibration or dropping.

Non-use Periods

◆ Switch the product to standby status or turn off the power when the product will not be used. Unplug the power cord from the AC outlet when the product will be idle for a long period of time.

Do not insert fingers or other objects into the product

◆ It may damage the product or even hurt human body by touching any internal parts of the product because of high voltage.

◆ Do not dismantle the product.

◆ Do not stack any object on the product.

Keep water and magnetic things away

◆ Contact with liquid may cause serious damage, please keep the product away from it.

◆ Keep product far away from magnetic things, such as speaker etc.

Position

◆ Place the product on a horizontal surface. Do not stack heavy things on it.

◆ Do not place the product beneath the magnifier or other devices that emit heat.

Signal Interference

◆ Under the condition of TV signal receive situation, TV Set may get signal interference when you are


watching a TV program with the DVB-S on. This is not means that the product or the TV Set is malfunction. Please turn off the DVB-S while watching the TV.

1.1.3 Features

- ◆ Fully MPEG-2 / DVB-S/DVB-S2 Compliant
- ◆ C/Ku Band and Horizontal/Vertical Polarized Program
- ◆ OSD Menu
- ◆ Electronic Program Guide (EPG)
- ◆ Multi-Programmable Channel (Favorite/Move/Lock/Delete/Sort)
- ◆ Satellite Signals Display
- ◆ Go-to-X
- ◆ Support 22 KHz DisEqC1.0 and DisEqC1.2 control, Unicable
- ◆ Editable for Satellites and Transponder's information
- ◆ QPSK Demodulation Mode, SCPC and MCPC Compatible
- ◆ Capacity of 6000 programs
- ◆ Auto scan/ Manual Scan/NIT Scan
- ◆ OSD/VBI Teletext Output
- ◆ TV SCART
- ◆ L/R Audio Output
- ◆ Digital Coaxial Output
- ◆ Power memory
- ◆ USB
- ◆ HMDI
- ◆ LCN Short-Circuit Power Protection
- ◆ OTA & USB Upgrade

1.1.4


1.1.5 Front Panels



1. **Power/Standby Button**
2. **CH- Button**
3. **CH+ Button**
4. **IR Receiver Window**
5. **USB LED Indicator**
6. **Power/ Standby LED Indicator**
7. **Display Window**
8. **CI-Module Slot**

The LED indicator goes Green in POWER mode and goes Red in STANDBY mode.

1.1.6 Rear Panel




- | | |
|---|--|
| <ol style="list-style-type: none"> 1. VCR SCART Socket 2. HDMI Socket 3. USB Port 4. TV SCART Socket 5. ZF IN 6. ZF OUT | <ol style="list-style-type: none"> 7. Audio Output - Left 8. Audio Output - Right 9. Digital Coaxial Output 10. Video Output 11. AC IN |
|---|--|

NOTE:

In order to avoid electric leakage and shock caused by scratched power cord, please unplug the power cord from the wall outlet and keep it orderly if the product is not going to be used for a long period time.

About Remote Control

Remote control	Name	Descriptions	
 <p>The diagram shows a MEGASAT HD570CI remote control. Numbered callouts point to the following features:</p> <ul style="list-style-type: none">1: POWER button2: F2 button3: MODE button4: Numeric keypad (1-9, 0)5: MENU button6: EXIT button7: Directional pad (Up, Down, Left, Right) and OK button8: VOL+ and VOL- buttons9: CH- and CH+ buttons10: TXT button11: SUB button12: USB button13: FIND button14: LIST button15: AUDIO button16: ZOOM button17: RECALL button18: Playback controls (Fast Rewind, Play/Pause, Fast Forward, Stop)19: MUTE button20: TV/R button21: F1 button22: FAV button23: EPG button24: SAT button25: INFO button26: SLEEP button27: PAGE DOWN button28: Mosaic button29: PAGE UP button30: CH- button31: CH+ button32: OK button33: INFO button34: SAT button35: EPG button36: FAV button37: Timer button38: MUTE button39: F1 button40: TV/R button	1	Power	Switch your device on from standby mode.
	2	F2	
	3	MODE	Change HDMI output resolution.
	4	Numeric Buttons	Select channel or programming parameters. Press numeric button 0 to switch to sleep mode.
	5	MENU	Enter in setup interface.
	6	EXIT	Exit from current menu.
	7	Navigation Buttons	Move cursor.
	8	VOL+	Turn up volume.
	9	VOL -	Turn down volume.
	10	TXT	Display teletext.
	11	SUB	Display subtitle.
	12	USB	Switch to USB mode.
	13	FIND	Enter in search interface.
	14	LIST	Enter in video list.
	15	AUDIO	Change audio track.
	16	PREV	Back to previous.
	17	NEXT	Skip to next.
	18	SLOW	Slow down play speed.
	19	PLAY/ PAUSE	Start playing. Make a pause.
	20	STOP	Stop.
	21	REC	No function
	22	F.RWD	Fast backward.
	23	F.FWD	Fast forward.
	24	Zoom	Zoom in or out.
	25	Recall	Back to previous channel or menu.
	26	SLEEP	Switch in standby mode.
	27	PAGE DOWN	Page down.
	28	Mosaic	Grid show.
	29	PAGE UP	Page up.
	30	CH -	Skip to previous channel.
	31	CH +	Skip to next channel.
	32	OK	Display channel list on screen. Confirm selection.
	33	INFO	Display information of current program.
	34	SAT	Shift satellites.
	35	EPG	Display Electronic Program Guide information of current channel.
	36	FAV	Shift to favorite channels.
	37	Timer	Enter in timer setup interface.
	38	F1	Multifeed.
	39	MUTE	Enable or disable the audio.
	40	TV/R	Shift between TV and radio.

Start

Battery installation


1.1.7 Install the batteries and make sure the positive (+) and negative (-) polarities match as shown in Figure A.

Service life of batteries

- ◆ The batteries normally last for about one year despite that it depends on how often and in what way the remote control is operated.
- ◆ Replace the batteries if the remote control fails to work even when it is operated near the DVB-S receiver.
- ◆ Use 2 pieces of 7 (AAA/UM-4) batteries.

Notes

- ◆ Do not use rechargeable (Ni-Cd) batteries.
- ◆ Do not attempt to recharge, short circuit, disassemble, heat the batteries or dispose of in fire.
- ◆ Do not drop or step on the remote control unit or subject it to shocks. Otherwise the parts of the remote control unit may get damaged and lead malfunction.
- ◆ Do not use the new and old batteries together.
- ◆ Please remove the batteries if the remote control is not going to be used for a long period of time. Otherwise, it may cause electrolyte leakage and lead malfunction, even fire accidents. Carefully wipe the electrolyte out of the remote control compartment and replace with new batteries. If any electrolyte happens to touch your skin, wash it off thoroughly with clean water immediately.




Operation range of remote control

- ◆ Point the remote control to the IR receiver window. The remote control shall be effective within a distance of about 5 meters and an angle of about 60 degrees as shown in Figure B.
- ◆ The effective range may vary slightly with the brightness of the room.

Notes

- ◆ Do not shine bright light to the remote control sensor.
- ◆ The remote control unit may not work if there are obstacles between the remote control and the sensor.
- ◆ Do not recommend this remote control using for other products.



1.1.8 Start

1.1.9 Basic Connections

Preparation


- ◆ All equipments **must be** connected according to this user manual.
- ◆ Switch off this product and other equipments before connecting
- ◆ Read the User Manual carefully before connecting other equipments
- ◆ Plug the Audio and Video cable correctly
- ◆ When connecting this product with TV set, only one kind of video output format will be accepted. Please choose a corresponding video output mode for the product, otherwise the image will be distorted.

NOTE

Users can choose any proper video output formats according to the TV socket and personal requirements.


Connecting antenna, VCR and TV-set (Figure C)

1. Antenna (Not included)
2. TV Set (Not included)
3. SCART cable for connecting TV set and DVB-S receiver (Not included)
4. AC IN



Connecting to TV-Set with HDMI/USB Socket (Figure D)

1. Antenna (Not included)
2. TV-Set (Not included)
3. HDMI Cable (Not included)
4. AC IN



Start

Fast Installation

Connect this unit and other apparatus according to "BASIC CONNECTIONS". Plug the power cord, press [STANDBY] button (no need for first connection) to start.

1. Plug the power cord and press [STANDBY] button to start.
2. Press [MENU] button to setup. Press [▲/▼] button to select "Tools" and load factory default. Default password is "0000".
3. Select "Installation" by press [CH-/CH+] button and press [VOL▶] button to setup. Password: 0000.
 - A. Select "Satellite List" to choose satellite. Press [EXIT] button to exit after setup.
 - B. Select "Antenna Setup" and press [VOL▶] to setup. Select "LNB Freq" to setup High Frequency and other parameters. Press [EXIT] button to exit after setup.
 - C. Select "Single/Multi Satellite" and press [VOL▶] to setup. After setup, press [VOL▶] to start auto search.

Read Menu Operation Instruction for more details.

Advanced Operation

Menu Operation

Main Menu

Press MENU button to browse the Main Menu which includes 5 sub-menus are listed below:

- ◆ Edit Channel
- ◆ Installation
- ◆ System Setup
- ◆ Tools
- ◆ Game

Press [CH▲/▼] button to select menu item, press OK button to browse its submenu. Press [EXIT] button to return to the previous menu.

Notes:

1. The four navigation buttons (▲/▼/◀/▶), OK and EXIT button have same functions in all levels menus.
2. Some buttons have different functions in different menus. Please find out according to the screen.
3. Programmable buttons (which with color) functionality depends on the menu that is active at press moment. Please find out according to the screen.

1. Edit Channel

Select Edit Channel in Main menu and press [OK] button to enter in its submenu. There are 4 options to choose which are listed below.

- ◆ TV Channel List
- ◆ Radio Channel List
- ◆ Delete All
- ◆ Save as Default

1.1 TV Channel List

Move cursor to "TV Channel List" and press [OK] button to enter in its setup interface. Use [CH▲/▼] button and press [OK] button to confirm. Use programmable buttons (which with color) to set up according to screen. Favor button is activated when the favorite channels have been set. Default Password is: 0000.

- **FAV:** Press [FAV] button to lift the "FAV" icon. Use [CH▲/▼] button to select channel and press [OK] button to set chosen channel in 8 different favorite groups. Press [OK] button twice to cancel setup. Press [EXIT] button to quit.
- **Lock:** Press [RED] button to lift the "Lock" icon. Use [CH▲/▼] button to select channel and press [OK] button to lock, press [OK] button again to cancel lock. Press [EXIT] button to quit current menu and save according to screen.
- **Skip:** Press [Green] button to lift the "Skip" icon. Use [CH▲/▼] button to select channel and set the chosen TV program to be skipped when use [CH▲/▼] button to shift channels.
- **Move:** Press [YELLOW] button to lift "Move" icon. Use [CH▲/▼] button to select channel and press [OK] button to confirm selection. Use [CH▲/▼] button to move and [OK] button to confirm movement. Press [EXIT] to quit current. Save according to screen.
- **Edit:** Press [BLUE] button to enter in "edit" interface. In "Edit" interface, press [RED] button to sort channels by Name (A-Z)/Name (Z-A)/Free/Scramble/Lock; press [GREEN] button to edit (rename) the chosen channel, Press [RED] button to shift alpha between capitalized and small, Press [GREEN] button to delete input, press [YELLOW] button to confirm, press [BLUE] button to cancel; press [BLUE] button to delete the chosen channel.

1.2 Radio Channel List

All found radio channels will be listed here.

Refer to the operation of TV Channel List (Item 1.1) for detailed operations.

1.3 Delete All

Delete all TV and radio programs according to screen.

1.4 Save as Default

Please operate according to screen.

2. Installation

Select installation in main menu and press [OK] button to enter in its submenu. There are 9 submenu items which are listed below.

- ◆ Antenna Connection
- ◆ Satellite List
- ◆ Antenna Setup
- ◆ Single Satellite Search
- ◆ Multi-Satellite Search
- ◆ TP List

2.1 Antenna Connection

- ◆ Fixed Antenna
- ◆ Motor Antenna

2.2 Satellite List

Move cursor to "Satellite List" and press [OK] button to enter in its submenu. Use [CH▲/▼] buttons to choose satellite.

- **Edit:** Press [RED] button to edit satellite. Please operate according to screen. Use [RED] button to shift alpha between capitalized and small. Use [GREEN] button to delete input. Use [YELLOW] button to confirm editor. Press [BLUE] button to cancel editor.
- **Add:** Press [GREEN] button add a satellite. Please operate according to chapter "Edit".
- **Delete:** Use [CH▲/▼] buttons to select satellite and [OK] button to confirm selection. Press [BLUE] to delete the selected satellite. Press [EXIT] button to quit and save according to screen.

2.3 Antenna Setup

Move cursor to "Antenna Setup" and press [OK] button to enter in its submenu. Use [CH▲/▼] buttons to select item and [VOL◀/▶] buttons to change parameters. Signal Intensity and Signal Quality will be displayed at bottom of the window.

- **Satellite:** Choose a satellite.
- **LNB Freq:** Press [OK] button to select a proper LNB Frequency.
- **Transponder:** Press [OK] button to select a transponder.
- **DiSEqC1.0:** Press [OK] button to select a digital control port.
- **22K :** Use [VOL◀/▶] buttons to activate or deactivate 22K Hz tone switch.
- **Polarity:** Use [VOL◀/▶] buttons to choose a polarity voltage: Auto, H(horizontal) and V(vertical).

2.4 Single Satellite Search

- **Satellite:** Press [OK] button to choose satellite.
- **FTA Only:** Yes(Search the free channels only)/No (Search both free and paid channels)
- **Scan Channel:** TV Channel/Radio/TV + Radio
- **Network Search:** Yes/No (It is activated when "Scan Mode" is in "Preset Scan" mode.)
- **Scan Mode:** Auto Scan/Preset Scan
- **Search:** Start search.

2.5 Multi Satellite Search

- **Satellite:** Press [OK] button to choose satellites for search.
- **FTA Only:** Yes(Search the free channels only)/ No (Search all channels)
- **Scan Channel:** TV Channel/Radio/TV + Radio
- **Network Search:** Yes/No (It is activated when "Scan Mode" is in "Preset Scan" mode.)
- **Scan Mode:** Auto Scan/Preset Scan
- **Search:** Start search.

2.6 TP List

Move cursor to "TP List" and press [OK] button to enter in its submenu. Press [EXIT] button to quit.

Refer to "Satellite List" for detail operations of Edit/Add/Delete/Search.

3. System Setup

Select Setup in main menu and press [OK] button to enter in its submenu. There are 11 submenu items which are listed below.

- ◆ Language
- ◆ TV System
- ◆ Display Setting
- ◆ Local Time Setting
- ◆ Timer Setting
- ◆ Conax Conditional Access
- ◆ Parental Lock
- ◆ OSD Setting
- ◆ Favorite
- ◆ Audio Description Setting
- ◆ Other

3.1 Language

- Language: English, French, Deutsch and etc.
- First Audio: English, French, Deutsch and etc.
- Second Audio: English, French, Deutsch and etc.
- Subtitle Language: English, French, Deutsch and etc.
- Teletext: English, French, Deutsch English, French, Deutsch and etc.

3.2 TV System

- Video Resolution
- Aspect Ratio : Auto/4:3 LB (Letter Box) / 4:3 PS(Pan Scan) / 16:9
- Video Out : RGB/HDMI

3.3 Display Setting

- Brightness: 0-100
- Contrast: 0-100
- Saturation: 0-100

3.4 Local Time Setting

- GMT Usage
- GMT Offset
- Summer Time
- Date
- Time

3.5 Timer Setting

- Timer Mode: once/daily/weekly/monthly/off.
- Timer Service
- Wakeup Channel
- Wakeup Date
- On Time
- Duration

Note: Wake up function is not available in Standby mode.

3.6 Conax Conditional Access

- Subscription Status : Check status of subscribed channel.
- Event Status : Check notice of operational company.
- Tokens Status) : Check balance of CA card.
- Change CA PIN : Setup a new PIN password.
- Maturity Rating : Amend limitation of channel levels, G/PG/A/X is available.
- About Conax CA : Check current CA card's information

3.7 Parental Lock

Default password: 0000

- Menu Lock: On/Off. Password will be required when auto scan or channel scan is activated if you choose "On" mode.
- Channel Lock: On/Off. Password will be required to watch locked programs.
- New Password: Set new password with numeric buttons.
- Confirm Password: Input the new password with numeric buttons.

3.8 OSD Setting

- Subtitle Display
- OSD Timeout: 1-10 seconds
- OSD Transparency: off/10%/20%/30%/40%

3.9 Favorite

There are 10 groups can be setup. Press OK button to rename the group.

- **YELLOW**: Switch capital and small letter
- **RED**: Cancel current input
- **BLUE**: Confirm input

3.10 Audio Description Setting

- AD Service: OFF/ON
- Use AD as default: OFF/ON
- AD volume offset: 0/1/2/3/-3/-2/-1

3.11 Other

- LNB Power: OFF/ON
- Channel Play Type: Free/Scrambled/All
- Ber: Off/On

4. Tools

Select Tools item and press [OK] button to enter in its submenu. There are 9 submenus which are listed below.

- ◆ Information
- ◆ Factory Setting
- ◆ Common Interface
- ◆ Upgrade by USB
- ◆ Media Player
- ◆ Save to USB
- ◆ Remove USB Device Safely

4.1 Information

View the system information of this product.

4.2 Factory Setting

Default password is "0000"

Common Interface

● **Slot1**

- 1) Set up information according to system inform of CI card.
- 2) Please insert card face up. If you find difficulties in insert card, please take it out and check the card is inserted right. Make sure the card is available.
- 3) PCMCIA Card is accepted with thickness no more than □-5.00mm.

Upgrade by USB

- Insert flash drive and load file named with "all*.abs".
- Enter in "Tools" menu and select "Upgrade by USB", press OK button to start upgrade.
- Select "ALL CODE", the upgrade file will be found automatically.
- Select "Start" to load the upgrade file and start upgrade.

Notes:

1. Do not cut off power supply during upgrade.
2. Factory default must be loaded after upgrade.

4.6 Save to USB

Insert flash drive and enter into "Save to USB" interface.

- Save Mode: All code/Radio back/ Default db
- Save File
- Start

4.7 Media Player (USB)

The device will automatically connect USB flash drive once it is inserted. Browse USB device files from "Media player" submenu which is located in "Tools" menu.

Notes:

1. MP3/JPEG/BMP formats are all supported.
2. Media player submenu can't be open without connecting USB device.
3. Press "EXIT" button to exit.

4.8 Remove USB Device Safely

Move cursor to "Remove USB Device Safely" and press [OK] button, wait for few seconds and remove the USB device safely.

5. Game

Select "Game" in "Tools" menu and press OK button to enter in its submenu. There are 2 submenus which are listed below.

- ◆ Othello
- ◆ Sudokuo

Appendix

Maintenance

- ☐ Unplug the power cord before maintenance.
- ☐ Keep the product surface clean. Soft cloth to clean the outer if it's dirty.
- ☐ Do not use any chemical products like Alcohol or dilution to clean the product.
- ☐ Refer all servicing to a qualified service agent.

Specifications

Items		Features
High Frequency Tuner	Input Frequency Range	950~2150 MHz (C/Ku Compatible)
	Input Signal Level	- 65 ~ - 30dBm
	RF Input Connector	IEC169 - 2, Female
	Input Impedance	75Ω
Demodulation Mode	Demodulation	QPSK , Compatible SCPC & MCPC
	Symbol Rate	2~45 Mbit/s
	Code Rate	1/2, 2/3, 3/4, 5/6, 7/8
Video Decoding	Video Decoding	ISO/IEC13818-2 MPEG2 (MP@ML)
	Video Resolution	720×576 (PAL) ; 720×480 (NTSC)
	Video Input Code Rate	15 Mbit/s Max
	Teletext	DVB-TXTETSI/EN300472
Audio Decoding	Audio Decoding	ISO/IEC13818 - 3
	Audio Track	Stereo, Monophony (L, R), SPDIF
	Audio Sample Rate	32 , 44.1, 48KHz
USB	USB Port	USB2.0
	Format	MP3/JPEG/BMP
	System	FAT32, NTFS
Power Specifications	Power Range	~ 176-264V , 50Hz
	Rated Power	~230V, 50Hz
	Standby Power Consumption	0,5 W ≤ 8W
	Rated Consumption	≤ 12W
Work Environment	Temperature	0~40℃
	Humidity	<90%
Dimensions	Weight	< 1.5 Kg
	Size	266(W)×188(D)×42(H)mm

Note:

Weight and dimensions are not absolutely exact values.
Specifications are subject to change (by manufacturer) without notice.

Troubleshooting

Look through the trouble shooting information. Some simple checks or minor adjustment of the unit on your part may help resolve the problems. If the problems prove to beyond your capability, you had better hand it over to a professional qualified technician.

The integrated circuits are easily breakdown by static. Make sure the antistatic protection has been well taken before maintenance.

Troubles	Possible Causes	Suggested Solutions
No power	The power cord has not been well connected	Plug the power cord into the outlet tightly and turn on the power; if no power still, turn off the power again, and turn it on in 5-10 minutes.
Can not scan programs	The antenna is not adjusted well	Adjust the antenna or use an outdoor antenna
	Use antenna incorrectly	Use an antenna with 75 Ω impedance input
	Parameter input incorrectly	Input Frequency, Bandwidth parameter correctly
No picture	Output cord connect incorrectly	Connect the output cord correctly.
	The video output mode of the unit is different from the mode of monitor	Reset the working system
No Color	The video output system of the unit is different from the mode of monitor	Reset the color system
Image distortion at channel shift	normal	
The remote control fails to work	Batteries incorrectly installed	Install the battery correctly
	Batteries exhausted	Replace the battery
	Beyond the effective operation range	Operate within an normal range
	The remote sensor is pointed to by bright light	Place the unit elsewhere for a change
Audio track and subtitle language are not the chosen items	Has not chosen the right sound track	Press the Audio button to shift the channel

No sound at all	The unit is in a mute status	Cancel the mute
	Volume set at a too low level	Augment the volume
	Cable connected incorrectly	Connect the cable correctly
No sound by chance	There might be a short circuit	Correct the output-cable connection, and turn on it.
	In mute status	Cancel the mute
	In standby mode	Turn on the unit
Serious distortion or cannot receive signal normally	Too much interferential signal	Adjust the antenna.
Flash drive can not be read	The flash drive has not been connected well	Connect the cable correctly.
	The flash drive's current is too heavy, the product wouldn't afford it.	Provide external power source.
	The flash drive runs self-protection program because of external device short circuit.	Change the short circuit device and restart the product.

MEGASAT

